



“Do It Yourself” Installation Guide

Install Instructions for: Auto Perforated Tiles

Materials Needed:

Utility Knife or Table Saw

Begin the installation in one corner, pointing the female loops in the directions that you will add tiles. The tiles simply snap together! Auto Perforated Tiles can be scored and cut with a utility knife or cut with a table saw.

Detailed installation instructions are available.