



# WOOD PERFORMA

Sheet Vinyl

## Initial Maintenance

Begin 48 hours after installation

- ALWAYS WEAR GOGGLES, GLOVES AND SLIP RESISTANT SHOES WHEN USING THIS PRODUCT.
- Install and maintain entry matting with a non-staining backing to reduce tracked-in dirt and contaminants.

### CLEAN:

- Remove dry soils (labels, gum). Sweep or microfiber dust mop floor. Place “Wet Floor” signs in area.
- Dilute 2 oz of **Floor Cleaner Care** to one gallon of cold water. Scrub with blue pad on auto scrubber or single disk machine.
- Pick up cleaning solution with scrubber or wet vac, replacing solution when mop water becomes dirty.
- Using a clean microfiber mop pad, damp mop any residue with clean water. Allow floor to dry completely.

### PRIME:

- Apply **Floor Primer Base Seal Coat** in one thin coat using a clean microfiber mop pad. Application of **Floor Primer Base Seal Coat** increases the adhesion of the floor finish to the floor.
- Allow to dry completely before applying floor finish. Dry time is subject to temperature and humidity.

### FINISH

- Apply **Floor Finisher** or **Floor Satin Ultra High Speed Matte Finish** in a thin coat using a clean microfiber mop pad.
- To apply a full, even coat, outline the area to be finished. Fill in the outlined area using a figure eight motion. Ensure perimeter and edges are completely coated.
- Apply a minimum of 2-4 coats. Allow 30 to 45 minutes between coats. For highly embossed products, 4 coats of floor finish is highly recommended.

Greatmats.com

117 Industrial Avenue, Milltown, WI 54858

Toll Free: 877-822-6622 - Fax Toll Free: 866-895-5550

Direct Voice: 715-825-4926 - Direct Fax: 715-825-4928

info@greatmats.com