



Humane Manufacturing LLC

### **Instructions on how to install our Loktuff flooring Islands & our 4' x 6' straight edge mats**

#### **Loktuff flooring installations:**

- 1) If the wall layout contains borders on 2 sides perpendicular to each other, lay those first.
- 2) Fill in rows and columns of center pieces until you get to the other two walls.
- 3) Then trim to fit.

**NOTE: When Humane mats are installed, the diamond surface needs to be on top.**

#### **How to trim the sides:**

- 1) The mats are easy to cut. A good utility knife with a sharp blade will do the job nicely, a jig saw works well too, or a reciprocating saw also works well.
- 2) You might want to have a can of WD-40 handy. The WD-40 gives the utility knife lubricant, to help cut through the rubber better. (Caution: when using WD-40, the lubricated knife will cut through the rubber with no problem, be careful not to cut yourself.)
- 3) Another helpful hint is to place a wooden 2 x 4 under the mat along the line of the intended cut creating an arch. By cutting along this arch, the mat will have a tendency to split and pull apart more easily as the knife is pulled through the mat.

#### **Loktuff Island installation:**

This type of installation is easy and doesn't require the use of tools. Just fit the pieces together. For reference a 31'1" x 29'9 1/2" island can be completely assembled in about 1 1/2" hours.

#### **4' x 6' mat installation:**

Start from a straight edge wall and work your way across the room. These mats just butt up next to each other. Since our mats are not always rectangular, some trimming is required, please follow the cutting instructions above. No adhesive is required. This is a loose lay product. When equipment is first rolled onto the mats for placement, some movement may occur depending on the thickness and size of your mat. There is no need to panic, once the equipment is in its place, the mats will lay flat and movement should not occur.