How to Install Artificial Turf Grass



GREATMATS

Introduction

Congratulations! You just bought your first rolls of Artificial Grass Turf. Well, now you are probably wondering how to install it. Look no further; this step-by-step guide will show you the way.

Before You Begin...

Let the turf relax for 30-60 minutes before the installation process due to it being delivered in rolls.

01 Clear Away Grass

Make sure the area you want to cover with turf is free of any grass, or other vegetation. Use grass blocker and weed killer so nothing can grow under the turf layer.



Add Decomposed Granite/Stone Aggregate and Level the Area





These are popular base materials that easily conform to a Gound's structure. They are also permeable, so they can provide a smooth finish for the turf. You can level the surface by using a water sod roller.

Once it is leveled, put 15-25 year weed barrier on top of the base. Then use landscaping staples to keep the barrier in place. You can then roll out the turf on top of the barrier.

03 Weed Barrier and Turf





O4 Cut the Turf and Seam Them Together

Use a box cutter to cut the turf to the area it is covering. If you are installing more than one piece of turf, you will need to seam them together using a seam cloth and a urethane-based adhesive.

05 Nail Down your Turf

After your turf is laid down and the seams are glued together, you can secure it by using 1-2 inch nails every 4-6 inches to attach it to the base. High-traffic areas should be stapled/nailed to pressure-treated wood around the perimeter.





O6 Fluff Grass and add Infill

Fluff the grass with a rake, so the infill can be poured on top. Add infill as recommended for particular product. Infill weighs the turf down and keeps the turf standing upright, giving it a natural grass feel. After you pour the infill, work it in evenly with the rake.



O7
Enjoy your
Turf!



Thank You

Do you have any questions?

info@greatmats.com | 877-822-6622 | greatmats.com









GREATMATS

