



Flexi-Wall Pad Roll Maintenance

Note: To prevent any infections, be sure to clean your wall pads regularly.

1. To clean FLEXI-Roll wall pads, first you will need to mix the Mat Attack™ mat cleaner disinfectant according to the directions on the bottle. You may also use a non-abrasive, multipurpose cleaner with disinfectant.
2. Next, spray with wall pad generously with the cleaner. With a microfiber or cotton towel, wipe the surface of the wall pad and allow to air dry.
3. To clean panel wall pads, spray a microfiber or cotton towel with the Mat Attack™ mat cleaner disinfectant mixture or a non-abrasive, multipurpose disinfectant. Use the towel to wipe the crevice between each panel. After you have cleaned the crevices between the panels, spray the wall pads generously with the cleaner. Wipe the surface of the wall pads and allow to air dry. Mat Attack™ mat cleaner is a disinfectant that is effective against a broad spectrum of bacteria that inhibits the growth of mold and mildew. It cleans, disinfects, and deodorizes in just a few easy steps.

Mat Attack is a registered Trademark of Dollamur Sport Surfaces.

Greatmats.com
117 Industrial Ave
Milltown, WI 54858
Toll free: 877-822-6622
Direct voice: 715-653-6100
Fax: 715-825-4928
info@greatmats.com
2/2025