

Eureka Interlocking Rubber Tile Installation

I. REQUIRED TOOLS & MATERIALS

Tape measure	Chalk line	Utility knife with heavy-duty blades
Metal Straight Edge	Framing square	Marking instrument such as paint pens or chalk
Push broom or vacuum		

II. SITE CONDITIONS

- A. **Inspect all tiles for visual defects before beginning installation. No labor claim will be honored on material installed with visual defects. Any discrepancies must be reported immediately to Greatmats Customer Service Department at 1-877-822-6622 before beginning installation.**
- B. Care should be taken when moving large or heavy equipment over interlocking tiles due to the modular free floating design of the system. Plywood or other rigid sheeting can be utilized to better disperse the load to avoid the buckle.
- C. This product is intended for indoor use only. Do not use where the flooring will be exposed to fuels, oils, solvents, chemicals, or large fluctuations in temperature.
- D. This product is not designed to be used under rolling loads or in commercial applications due to the loose lay design. If full adhesion is required please contact Greatmats for other recommended products.
- E. Areas to receive flooring should be weather tight and maintained at a minimum uniform temperature of 65°F (18°C) for 48 hours before, during, and after the installation.
- F. Install Interlocking Tiles over wood or concrete subfloors, or firmly adhered resilient flooring such as vinyl, linoleum, laminate, ceramic tile, and wood.
- G. Surface should be smooth to prevent irregularities, roughness, or other defects from transferring through to the new flooring.

III. MATERIAL STORAGE AND HANDLING

- A. Store the material in its original, unopened packaging with all labels intact.
- B. Inspect all materials for visual defects before beginning the installation. Verify the material delivered is the correct style, color, and amount. Any discrepancies must be reported to Greatmats Customer Service.
- C. Remove tiles from cartons and allow to sit in the area to be installed, at uniform room temperature 24 hours prior to installation.
- D. Mix tiles from several boxes or skids. Ensure that job site and subfloor conditions are met.
- E. Install Interlocking Tiles so that the directional markings stamped on the bottom of the tiles point in the same direction. It is mandatory to install these tiles in the same direction.

Eureka Interlocking Rubber Tile

Installation - continued

V. SUFACE CLEANING

- A. Remove all surface soil and debris by sweeping or vacuuming.
- B. Damp mop to remove additional soil using ECleaner, diluted per the manufacturers' instructions.

DO NOT flood the floor with water as the Interlocking mat is permeable and will allow water to pass through. For tough stains or dirt build up, a nylon brush may be used in conjunction with the recommended ECleaner.

Greatmats.com
117 Industrial Ave
Milltown, WI 54858
Toll free: 877-822-6622
Direct voice: 715-653-6100
info@greatmats.com
Revised 11/2023