

G-Floor Garage Flooring Installation

Quick Start Guide

1. Sweep and clean the floor thoroughly
2. Unroll mat starting from the entrance
3. Let mat relax for up to 72 hours in cooler temps
4. Optional: trim edges for custom fit
5. Secure with double-sided tape, seaming tape, or adhesive if needed

Installation Types

- **Floating Mat:** No adhesive needed. Leave a 1-inch gap from walls/heavy items
- **Adhered Installation:** Use acrylic or pressure-sensitive adhesive for full-floor coverage
- Outdoor installation requires full adhesion to substrate.

Common Accessories

- **Seam Tape:** Joins mats underneath while allowing movement
- **Center Trim:** Covers seams and prevents tripping
- **Edge Trim:** Finishes edges with a tapered look
- **Threshold Trim:** Prevents dirt, bugs, and moisture from entering

Tips

- Leave a 1" gap from walls or poles
- Use adhesive if heavy items will sit on the mat
- Use tape only on the leading edge—not the entire perimeter
- Trim around drains or obstacles as needed

Greatmats.com
117 Industrial Ave
Milltown, WI 54858
Toll free: 877-822-6622
Direct voice: 715-653-6100
Fax: 715-825-4928
info@greatmats.com
Revised 1/2025