

Walk behind Tape Dispenser for 3 Inch Vinyl Tape Assembly

- Take each piece out of box and lay out.
- Find the base frame piece. One side will be small and narrow and the other side will be wide.
- Take the smaller wheel and attach (with the included hardware) it to the smaller side of the base.
- Take the larger wheel and attach it (with the included hardware) to the wider part of the base.
- Your wheels should now be installed on to the base of the tape dispenser.
- Find the pole with an attached handle and tape holder. Attach this piece with the included hardware. Make sure the tape holder is facing up and out.
- To install a roll of tape place the roll of tape in the holding system making sure when you pull the tape out the sticky side is face up. Pull down the tape and wind it slightly around the thick black roller on the bottom of the dispenser.
- Push the roller along the seam you wish to tape, using the small black roller in front as a guide.



Greatmats Specialty Flooring
117 Industrial Ave.
Milltown, WI 54858
1-877-822-6622
info@greatmats.com
www.greatmats.com