

Horse Stall Mat-Straight Edge Installation Instructions



The Package

This is how you receive your product. You will need to prepare your subsurface.



Stall mats can be placed over concrete, asphalt, wood or any level well-compacted surface. The gentlemen to the left are using decomposed granite, you can also use limestone fines, just make sure the fines do not exceed 1/8" in size. Fines are easy to work with, compact well, provide good drainage, and stand up well to freeze/thaw conditions. The fines should be installed to a depth of 4 to 5 inches, which may require excavating some of the existing material to maintain current stall elevations. Once you fill the stall base, use a board (the thickness of our mats) to ensure you have the perfect the level for stall.

Once you have the correct amount of fines in the stall, level and tamp the fines. Use water to soak the material, aiding in the compaction process.



Now that the subsurface is level and compacted, let it dry and you are ready to install the mats. Start in one corner of the stall and fit pieces together like puzzle. Because rubber can expand and contract, we recommend that you leave a 1/4" to 1/2" gap between the edge of the mat and the stall wall.



The Finished Stall: now add a small amount of bedding, and your horse can enter its new home. You will spend less time mucking the stall and more time enjoying your horse.

Greatmats.com
117 Industrial Ave
Milltown, WI 54858
V: 877-822-6622
F: 866-895-5550
info@greatmats.com
revised 3/2015