



Wall Pad Softwall Panels with Nail Margin Top and Bottom Mounted Fir Stripping Installation Instructions

Begin by striking a chalk line along the wall to mark the top edge of the panel.

Typical Strike the line 4" more than the height of the panel. (eg panel measures 72" the line should be struck at 76") you can adjust the panel to a lower height if desired, however the bottom edge of the foam should be a maximum of 4" above the floor.

Mounting Panels to 1 x 3 fir stripping. Panels with 1" nail margins top and bottom

Fastener Suggestions: Fir to #1 Concrete or Concrete Block –

2" or 2-1/4" concrete screws

OR

2" or 2-1/4" nail pin

Either selection will require drilling holes through the fir strip into the wall.

Use of construction adhesive is advised for the center of the panel

Also mount 1/4" x 1" piece of stripping (provided with your panels) on the wall in the centerline of the panels. This will help make the panels slightly convex on the wall and help keep the covers taught.

Proceed to mount panels with the correct fasteners.

Whenever possible begin installing panels in a left to right direction. Begin at the furthest point on the left - hold top edge of panel even with the line that was struck on the wall - plum panel – drill hole in top left corner (if going from left to right) set pin or screw top left corner - check plum again - drill panel in top right corner.

Make sure the panel is plumb. Finish top and bottom installation of panel with 2 anchors on the top and 2 anchors on the bottom.

If a panel layout has been provided by the factory, please refer to it so the panels are placed in their correct location. Panels are usually marked on the back with either letters or numbers or colors that refer back to the drawing.

Wall Pad Softwall Panels with Nail Margin Top and Bottom Mounted Fir Stripping

Installation Instructions – continued

Page 2
Read details on page 1

