



Wall Pad Softwall Panels with Nail Margin Top and Bottom Installation Instructions

Begin by striking a chalk line along the wall to mark the top edge of the panel.

Strike the line 4" more than the height of the panel. (eg panel measures 72" the line should be struck at 76") you can adjust the panel to a lower height if desired, however the bottom edge of the foam should be a maximum of 4" above the floor.

Mounting Panels directly to the wall (Concrete Block, Concrete, Wood or Drywall).

Panels with nail margins

Fastener Suggestions: #1 Concrete or Concrete Block –

1-1/4" or 1-1/2" concrete screws (flat head)

OR

1-1/4" or 1-1/2" nail pin

Either selection will require drilling 2 holes through the top and 2 holes through the bottom of the nail margins in the panel – and drilling holes into the wall with a hammer drill.

#2 Wood Wall – simply use a #8 x 1-1/4" flat head wood screw or 1-1/4" coarse thread drywall screw directly into the wood.

#3 Drywall – Nylon Toggle or some other suitable Hollow Wall Anchor you will need a minimum of 2 anchors on the top and 2 anchors on the bottom.

Use of construction adhesive is advised for the center of the panel

Also mount 1/4" x 1" piece of stripping (provided with your panels) on the wall in the centerline of the panels. This will help make the panels slightly convex on the wall and help keep the covers taught.

Proceed to mount panels with the correct fasteners.

Whenever possible begin installing panels in a left to right direction. Begin at the furthest point on the left - hold top edge of panel even with the line that was struck on the wall - plum panel – drill hole in top left corner (if going from left to right) set pin or screw top left corner - check plum again - drill panel in top right corner.

Make sure the panel is plumb. Finish top and bottom installation of panel with 2 anchors on the top and 2 anchors on the bottom.

If a panel layout has been provided by the factory, please refer to it so the panels are placed in their correct location. Panels are usually marked on the back with either letters or numbers or colors that refer back to the drawing.