



Installation of HVD Matting Rolls

Before You Begin

Lay the matting and edging out flat in a clean dry area to acclimate and relax.

This may take up to 24 hours.

In a cold environment, use a heat gun and weights to help relax the matting.



Installation of Matting

Matting is designed to be loose laid without being attached to the floor underneath.

Connector clips not recommended for pet areas.

Cutting the Mat

Measure the length and width of the mat needed.

Cut using a sharp utility knife and a straight edge.



117 Industrial Ave

Milltown, WI 54858

877-822-6622

info@greatmats.com