

Installation of Plastex Matting Rolls: Heronrib, Heronwalk

Before You Begin

Lay the matting and edging out flat in a clean dry area to acclimate and relax.

This may take up to 24 hours.

In a cold environment, use a heat gun and weights to help relax the matting.



Installation of Matting

Matting is designed to be loose laid without being attached to the floor underneath.

Connector clips can be used to temporarily join mats together.

Cutting the Mat

Measure the length and width of the mat needed.

Cut using a sharp utility knife and a straight edge.



Using Connector Clips

Connector clips are designed to connect mats together. Connector clips should be placed at regular intervals. No adhesive is necessary.

