



# EVENT HIGH GLOSS

Glossy Urethane Finish Dance Floor

## Initial and Daily Maintenance

- ALWAYS WEAR GOGGLES, GLOVES AND SLIP RESISTANT SHOES WHEN USING THIS PRODUCT.
- Install and maintain entry matting with a non-staining backing to reduce tracked-in dirt and contaminants.
- Sweep the entire area with a soft bristle broom or microfiber dust mop to remove dust and debris.
- Dilute 2 oz of **Floor Cleaner Care** to one gallon of cold water. Damp mop using a clean microfiber mop pad. Replace mop water when dirty.
- To remove scuff marks, buff area with a low speed machine or auto-scrubber equipped with a clean contact pad. Buff until clean and dry, changing pads as they get clogged.

Note: Always use quality pH neutral cleaning products. Do not use abrasive pads, brushes or cleaning agents.

The floor should always be clean to minimize any slip hazard from a build-up of dust and tracked-in contaminants. When the floor is properly cleaned, you will notice increased traction.

Greatmats.com  
117 Industrial Avenue, Milltown, WI 54858

Toll Free: 877-822-6622 - Fax Toll Free: 866-895-5550  
Direct Voice: 715-825-4926 - Direct Fax: 715-825-4928  
info@greatmats.com