

MATLAY CLEANING INSTRUCTIONS

Maintenance is a daily procedure
Daily Maintenance will extend the life of the flooring

UTENSILS NEEDED FOR CLEANING

- Clean Dust Mop
- Clean Mop
- Clean Mop Bucket
- Distilled White Vinegar
- Hot Water (As hot as you can get it)

INSTRUCTIONS

1. Thoroughly sweep the Matlay with a clean dust mop prior to mopping the floor.
2. Fill the mop bucket with three parts hot water and one part distilled white vinegar. You do not need to fill the bucket up all the way, however the ratio of 75% hot water to 25% distilled white vinegar should remain the same.
3. Apply intense force while mopping to remove the body oils and dirt. (Remember that body oils and dirt have been ground into the Matlay with countless hours of dancing. Barefoot dancing compound this situation)
4. Ensure the mixture you are using is hot and clean, which means you may need to change our the bucket multiple times while cleaning the Matlay. If you mop with the dirty and/or cold water you will just be spreading the dirt and oils around the floor. You will need to cut the oil with the hot water and vinegar to get it ip off the floor. When the bucket of water stays clear then all the oil is off the floor.

Greatmats.com
117 Industrial Ave - Milltown, WI 54858
info@greatmats.com