DANCE AND STAGE PRO

GREATMATS

Dance floor

Routine/Daily Maintenance

- ALWAYS WEAR GOGGLES, GLOVES AND SLIP RESISTANT SHOES WHEN USING THIS PRODUCT.
- Install and maintain entry matting with a non-staining backing to reduce tracked-in dirt and contaminants.

CLEAN:

- Remove gross soils (labels, gum). Sweep or microfiber dust mop floor. Place "Wet Floor" signs in area.
- Dilute 2 oz of **Floor Cleaner Care** to one gallon of cold water. (Replace solution when mop water becomes dirty.)
- Apply to finished floors using a clean microfiber mop pad, low speed machine or autoscrubber. Allow floor to dry completely.
- When dry, if needed, burnish with an ultra-high speed machine and blue ice pad to high gloss. Never burnish with a soiled pad. A minimum of 2 to 4 coats of floor finish should exist on the floor prior to being burnished.

PERIODIC SCRUB AND RECOAT (as needed):

- Dilute 2 oz of **Floor Cleaner Care** to one gallon of cold water. Scrub with blue pad on auto scrubber of single disk machine. Pick up cleaning solution with scrubber or wet vac. (Replace solution when mop water becomes dirty.)
- Using a clean microfiber mop pad, damp mop any residue with clean water. Allow floor to dry completely.

RECOAT:

- Apply Floor Finisher or Floor Satin Ultra high Speed Matte Finish in a thin coat using a clean microfiber mop pad. To apply a full even coat, outline the area to be finished. Fill in the outlined area using a figure eight motion. Ensure perimeter and edges are completely coated.
- Apply a minimum of 2 to 4 coats. Allow 30 to 45 minutes between coats. For highly embossed and porous products, 4 coats of floor finish is highly recommended. (To Keep clean follow DAILY MAINTENANCE directions.)

Greatmats.com

117 Industrial Avenue, Milltown, WI 54858

Toll Free: 877-822-6622 - Fax Toll Free: 866-895-5550 Direct Voice: 715-825-4926 - Direct Fax: 715-825-4928

info@greatmats.com